

SHINE

DISHWASHING DETERGENT

concentrate

Shine is mild but strong concentrated dish detergent for all kitchen utensils and dishes and for the cleaning of other waterproof surfaces. Surfactants in the product effectively disintegrate fat, proteins and ferments, and the product has very good fat emulsifying properties. Great washing outcome is insured when using cool and hard water. Dishes and glasses shine after washing.

PRODUCT PROPERTIES

- excellent cleaning result
 - odourless
 - colourant-free
 - neutral pH
 - for hand washing the dishes
 - suitable for people with sensitive skin
 - also suitable for cleaning surfaces
-

USAGE

Place the kitchenware in the solution and wash them with a sponge or a brush. Solution depends of water roughness and the soiling of the surface (up to 1:2000).

It's recommended to wash glasses and less soiled cutlery first and then kitchenware (pots, pans etc) and kitchen surfaces. After washing the dishes, rinse them with warm water that helps to dry faster. Dry your hands thoroughly but gently after washing the dishes, in order to keep your skin soft.

STORAGE

See the best before date on the package. Store at room temperature, keep away from direct sunlight and avoid freezing to assure the quality of the product.

UTILIZATION


Product is ecologically safe, all active ingredients are biodegradable in flush water. Plastic packaging materials are recyclable. For collection, the plastic packaging is suitable when rinsed, the bottle and cap separated. The packaging box is sorted for cardboard collection. The compatibility of the packaging and the product is quality assured.

COMPOSITION

sodium dodecylbenzene sulfonate, sodium chloride, benzyl alcohol, citric acid

pH 6

PACKAGES



1L bottle



Goodpoint Chemicals OÜ
Urda tee 2/1, Jälgimäe 76404,
Saku vald, Harjumaa, Estonia
www.goodpointchemicals.com
info@goodpointchemicals.com

